

Equipment to be used:

Double burner Camping Gas folding cookers (or similar)

Butane gas cylinders with regulators and "in date" approved hose and fittings

Risk Level	Risk to be Considered	Mediation	Mediated Risk Level	Review Comments	Notes
3	Risk of Fire	Ensure Fire Exits are clear	1		
3	Risk of gas leak	Ensure in-date hoses are used/ regulators checked/ check for leaks before and during use. Attaching/ detaching gas cylinder is to be done by an adult. Fire door to be unbolted and ajar.  No gas cylinder to be fitted or removed whilst any other cook station has a naked flame.  Connecting the gas cylinder is the first and last task for the adults supervising the activity	1		Regular checking of equipment before use is always carried out.
3	Stability of equipment	No faulty equipment to be used. Tables to be set up and legs locked in place	1		

3	Failure to light stove, allowing for gas escape	Always ensure that the gas control on the regulator is OFF when the cooker is not in use. Cooker controls in the OFF position when not in use regardless of regulator switch position. Gas should only be turned on when the cooker is in use, adult supervision to ensure that the gas is lit and has not gone out is a standard requirement.	1		
3	Faulty Gas valve resulting in a gas escape	Vacate the room via the nearest exit. Gas cylinder to be removed from the room via the Fire Exit. The gas should be allowed to escape if the seal cannot immediately be made.	1		In 30 years, this has only happened once.